



NOTES:

1. FASTENERS MUST PENETRATE INTO WOOD OR METAL STUDS, WHERE WALL IS BUILT WITH STUDS.
2. HP-X FASTENERS AND RhinoBOND PLATES ARE REQUIRED OVER STEEL AND WOOD DECKS.

<p>— THERMOPLASTIC MEMBRANE</p> <p>— APPROVED SUBSTRATE</p> <p>0 — SEE NOTE(S)</p>	<p>RhinoBond WALL ATTACHMENT</p> <p>For additional information, refer to Specifications</p>	<p>DETAIL NO.</p> <p>RB-4</p> <p>RhinoBond</p>
------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------	------------------------------------------------